


AA341 Decal Customisation


The AA341 is supplied with decals to customise the buttons on the handset. Select the decal for your system and apply to the top of the handset.




Example:
Decal applied for windlass
and thruster control




Dual Speed
Windlass Control
Top = Fast
Bottom = Slow



Windlass & Thruster
Control
Top = Windlass
Bottom = Thruster



Windlass Plus Deck
light and wash
Top = Windlass
Bottom = Light &
Wash




Windlass plus Open and
Close switch (eg hatch or
transom)
Top = Windlass
Bottom = Open & close

AA341 Decal Customisation


The AA341 is supplied with decals to customise the buttons on the handset. Select the decal for your system and apply to the top of the handset.




Example:
Decal applied for windlass
and thruster control




Dual Speed
Windlass Control
Top = Fast
Bottom = Slow



Windlass & Thruster
Control
Top = Windlass
Bottom = Thruster



Windlass Plus Deck
light and wash
Top = Windlass
Bottom = Light &
Wash



Windlass plus Open and
Close switch (eg hatch or
transom)
Top = Windlass
Bottom = Open & close